


MICROWAVE OVEN

Service Manual

Model: KOR-804M



PRECAUTIONS TO BE OBSERVED BEFORE AND DURING SERVICING TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not operate or allow the oven to be operated with the door open.
- (b) Make the following safety checks on all ovens to be serviced before activating the magnetron or other microwave source, and make repairs as necessary: (1) Interlock operation, (2) proper door closing, (3) seal and sealing surfaces (arcing, wear, and other damage), (4) damage to or loosening of hinges and latches, (5) evidence of dropping or abuse.
- (c) Before turning on microwave power for any service test or inspection within the microwave generating compartments, check the magnetron, wave guide or transmission line, and cavity for proper alignment, integrity, and connections.
- (d) Any defective or misadjusted components in the interlock, monitor, door seal, and microwave generation and transmission systems shall be repaired, replaced, or adjusted by procedures described in this manual before the oven is released to the owner.
- (e) A microwave leakage check to verify compliance with the Federal performance standard should be performed on each oven prior to release to the owner.

TABLE OF CONTENTS

PROPER USE AND SERVICE PRECAUTIONS	2
SPECIFICATIONS	3
NAMES AND FUNCTIONS OF PARTS	4
INSTALLATION	5
OPERATION	7
PRECAUTIONS FOR DISASSEMBLY AND REPAIR	20
MEASUREMENT	21
MICROWAVE RADIATION TEST	22
WIRING DIAGRAM	23
CIRCUIT DESCRIPTION	24
INTERLOCK MECHANISM	27
DISASSEMBLY AND ASSEMBLY	29
TROUBLE SHOOTING GUIDE	34
COMPONENT TEST PROCEDURE	41
PRINTED CIRCUIT BOARD	43
CIRCUIT CHECK PROCEDURE	
COMPONENT INFORMATION	
PRINTED WIRING BOARD	
P.W.B. LOCATOR NO.	
P.W.B. CIRCUIT DIAGRAM	
EXPLODED AND PARTS LIST	53

CAUTION: This Device is to be Serviced Only by Properly Qualified Service Personnel. Consult the Service Manual for Proper Service Procedures to Assure Continued Safety Operation and for Precautions to be Taken to Avoid Possible Exposure to Excessive Microwave Energy.

PROPER USE AND SERVICE PRECAUTIONS

1. For Safe Operation

Damage that allows the microwave energy (that cooks or heats the food) to escape will result in poor cooking and may cause serious bodily injury to the operator.

IF ANY OF THE FOLLOWING CONDITIONS EXIST, OPERATOR MUST NOT USE THE APPLIANCE.

(Only a trained service personnel should make repairs.)

- 1) A broken door hinge.
- 2) A broken door viewing screen.
- 3) A broken front panel, oven cavity.
- 4) A loosened door lock.
- 5) A broken door lock.

The door gasket plate and oven cavity surface be kept clean.

No grease, soil or spatter should be allowed to build up on these surfaces or inside the oven.

DO NOT ATTEMPT TO OPERATE THIS APPLIANCE WITH THE DOOR OPEN. The microwave oven has concealed switches to make sure the power is turned off when the door is opened. Do not attempt to defeat them.

DO NOT ATTEMPT TO SERVICE THIS APPLIANCE UNTIL YOU HAVE READ THIS SERVICE MANUAL.

2. For Safe Service Procedures.

- 1) If the oven is operative prior to servicing, a microwave emission check should be performed prior to servicing the oven.
- 2) If any certified oven unit is found to have excessive emission level $5\text{mW}/\text{cm}^2$, the service person should:
 - (a) inform the manufacturer, importer or assembler,
 - (b) repair the unit at no cost to the owner,
 - (c) attempt to ascertain the cause of the excessive leakage,
 - (d) tell the owner of the unit not to use the unit until the oven has been brought into compliance.
- 3) If the oven operates with the door open, the service person should tell the user not to operate the oven and contact the manufacturer and CDRH immediately.


CAUTION **MICROWAVE RADIATION**

PERSONNEL SHOULD NOT BE EXPOSED TO THE MICROWAVE ENERGY WHICH MAY RADIATE FROM THE MAGNETRON OR OTHER MICROWAVE GENERATING DEVICE IF IT IS IMPROPERLY USED OR CONNECTED. ALL INPUT AND OUTPUT MICROWAVE CONNECTIONS, WAVEGUIDE, FLANGES AND GASKETS MUST BE SECURE. NEVER OPERATE THE DEVICE WITHOUT A MICROWAVE ENERGY ABSORBING LOAD ATTACHED. NEVER LOOK INTO AN OPEN WAVEGUIDE OR ANTENNA WHILE THE DEVICE IS ENERGIZED.


SPECIFICATIONS

Item	Rating Specification
Power Supply	230V Single phase with grounding 50Hz AC.
Power Consumption	1400 W
Microwave Output Power	900 W: Full Microwave power
Microwave Frequency	2450 MHz
Outside Dimensions	485 (W) × 361 (D) × 330 (H) mm
Cavity Dimensions	310 (W) × 310 (D) × 245 (H) mm
Cavity Volume	0.90 Cu.ft. (24 ℓ)
Net Weight	17 Kg
Timer	Digital timer 99 min. 99 sec.

**Specification subject to change without notice.*



NAMES AND FUNCTION OF PARTS



- ① **Door Hook**—When door is closed, it will automatically lock shut. If door is opened while oven is operating, magnetron will immediately stop operating.
- ② **Door Seal (Microwave absorber)**—Door seal maintains the microwave within the oven cavity and prevents microwave leakage.
- ③ **Cabinet**
- ④ **Suction Air Vents**—To cool the interior.
- ⑤ **Safety Interlock System**
- ⑥ **Oven Cavity**
- ⑦ **Door Release Button**—By pushing this button the interlock switch cuts off all circuit and stop the oven before the door can be opened.
- ⑧ **Turntable**—Made of special heat-resistant glass. Tray must always be in proper position when oven is operating.
- ⑨ **Roller Guide**—To support the glass turntable.
- ⑩ **Door Viewing Screen**—Allows viewing of food. The screen is designed so that light can pass through, but not the microwave.
- ⑪ **Meat Pad**—Touch to defrost meat.
- ⑫ **Poultry Pad**—Touch to defrost poultry.
- ⑬ **Fish Pad**—Touch to defrost fish.
- ⑭ **Auto Reheat Pad**—Touch to set only desired program reheat setting.
- ⑮ **More Pad**—Touch to add on extra seconds of cooking time when the AUTO REHEAT is selected.

- ⑩ **Less Pad**—Touch to remove seconds of cooking time when the AUTO REHEAT is selected.
- ⑪ **Auto Defrost Pad**—Touch this pad, then the desired number pads to set the defrosting time.
- ⑫ **Time Pad**—Touch this pad, then the desired number pads to set the cooking time.
- ⑬ **Power Level Pad**—Touch this pad, then the desired number pads to enter the power level.
- ⑭ **Number Pads**—Used to set the cooking time, power level and weight.
- ⑮ **Clock Pad**—Touch to set the present time.
- ⑯ **Pause/Clear Pad**—Used to stop the oven operation or to delete the cooking data.
- ⑰ **Auto Start Pad**—Touch this pad to auto start the oven.
- ⑱ **Start Pad**—Used to start a selected operation.
- ⑲ **One minute Repeat Pad**—Touch this pad, the oven operate for one minute on high power. If you've touched this pad after ending the stage cook 1 or 2, the oven cooks at the previously selected power level for one minute.

INSTALLATION

1 **Steady, flat location**

This microwave oven weighs 17kg, so it should be set on a steady, flat location.

2 **Leave space behind and side**

All air vents should be kept a clearance. If all vents are covered during operation, the oven may overheat and, eventually, cause oven failure.

3 **Away from Radio and TV sets**

Poor television reception and radio interference may result if the oven is located close to a TV, Radio, or Antenna, feeder and so on.

4 **Away from heating appliances and water taps**

Keep the oven away from hot air, steam or splash when choosing a place to position it, or the insulation might be adversely affected and breakdowns occur.

5 **Power supply**

- **Check your local power source.**
This microwave oven requires a current of approximately 6 amperes 230V 50Hz.
Use a receptacle that will accept the ground prong.
- **Voltage Warning**
The voltage used must be the same as specified on this Microwave Oven.
Using a higher voltage may result in a fire or other accident causing oven damage. Using low voltage will cause slow cooking.
We are not responsible for damage resulting from use of this Microwave Oven with a voltage or amperage fuse other than those specified.

OPERATION PROCEDURE

This section includes useful information about oven operation.

1. Plug power supply cord into standard 3-pin earthed 8 Amp, 230V AC 50Hz power outlet socket.
2. After placing the food in a suitable container, open the oven door and put it on the glass tray.
The glass tray must always be in place during cooking.
3. Shut the door. Make sure that it is firmly closed.
- 1 When the oven door is opened, the light turns off.
- 2 The oven door can be opened at any time during operation by touching the door release button on the control panel. The oven will automatically shut off. To restart the oven, close the door and then touch START.
- 3 Each time a pad is touched, a BEEP will sound to acknowledge the touch. One of the function pads must be touched before the number pads. Therefore, no beep will sound if the numeral pad is touched before the function pad.
- 4 The oven automatically cooks on full power unless set to a lower power level.
- 5 The display will flash "1:00" when the oven is plugged in.
- 6 Time clock returns to the present time when the oven turns off.
- 7 When the PAUSE/CLEAR pad is touched during the oven operation, the oven stops cooking and all information is retained. To erase all information (except the present time and memory data), touch the PAUSE/CLEAR pad once more. If the oven door is opened during the oven operation, all information is retained.
- 8 If the START pad is touched and the oven does not operate, check the area between the door and door seal for obstructions and make sure the door is closed securely.
The oven will not start cooking until the door is completely closed or the program has been reset.

Make sure the oven is properly installed and plugged into the electrical outlet.

IMPORTANT: This appliance must be earthed.

Wattage output chart

*Number pads represent the following when used to select power level.

Pad Number	Power Level	Power
1	1	(10 %)
2	2	(17 %)
3	3	(28 %)
4	4	(38 %)
5	5	(48 %)
6	6	(59 %)
7	7	(69 %)
8	8	(79 %)
9	9	(90 %)
10	10	(100 %)

OPERATION

SETTING THE CLOCK


When the oven is first plugged in, the Display will flash "1:00" and a tone will sound. If the AC power ever goes off, the Display will flash "1:00" when the power comes back on.

DO THIS...

THIS HAPPENS...



1. Touch **CLOCK**.




The colon stops blinking and a tone will sound.

Example



2. Touch the Number Pads to set the present time.




The Display will show what numbers you pressed in the order you pressed them.

This example shows "10:10".

NOTE: The colon will continue to stop.



3. Touch **CLOCK** pad to confirm the clock time.



The Display will show the present time, and the colon starts blinking. This digital clock allows you to set from 0:00 to 23:59.

If you've programmed in an incorrect time such as "24:24", the time will not be set and the clock will not work.

If this occurs, reset the clock.

AUTO DEFROSTING


When AUTO DEFROST is selected, the automatic cycle divides the defrosting time into periods of alternating defrost and stand times by cycling on and off. This provides a more even defrosting.

DO THIS...

THIS HAPPENS...



1. Touch the AUTO DEFROST pad.




The AUTO DEFROST Indicator Light will come on.

Example

② ⑦ ① ① ① ① ① ① ① ①


2. Touch Number Pads for the defrosting time you want.



The Display will show the numbers you pressed in the order you touched them. This example shows 27 minutes 10 seconds.



3. Touch the START pad.



When you touch START, the AUTO DEFROST Indicator Light starts blinking to show the oven is in the Auto Defrost mode.

The Display counts down the time to show you how much defrosting time is left in the Auto Defrost mode.

Turn over, break apart and redistribute at a beep.

When the defrosting time ends, you will hear 3 beeps.

AUTO WEIGHT DEFROSTING

AUTO WEIGHT DEFROST lets you easily defrost food by eliminating guesswork in determining defrosting time. The minimum weight for Auto Weight defrost is 200 grams. The maximum weight for Auto Weight Defrost is 3000 grams. Follow the steps below for easy defrosting.


DO THIS...

THIS HAPPENS...

Example



1. Touch the selected food item pad.




The POULTRY & g Indicator Light and minimum weight "200" is displayed.

If you wish to enter a new food item, press MEAT or FISH.

Example



2. Touch Number Pads for the defrosting weight you want.




The Display will show the numbers you pressed in the order you touched them.

This example shows 350 gs.

Set the weight of your meat, poultry, fish by touching the appropriate number pads to the nearest 10th of a gram.



3. Touch the START pad.



When you touch START, the POULTRY Indicator Light starts blinking to show the oven is in the Auto Weight Defrost mode.

The Display counts down the time to show you how much defrosting time is left in the AUTO WEIGHT DEFROST mode.

Turn over, break a part and redistribute at a beep.

When the defrosting time ends, you will hear 3 beeps.

If you've programmed an incorrect weight such as "4000" reset the Auto Weight Defrost. If this occurs, the Display will show "200".


COOKING IN ONE STAGE

DO THIS...

THIS HAPPENS...



1. Touch the TIME pad once.




STAGE 1 Indicator Light will come on.

Example




2. Touch the Number Pads for the cooking time you want.



The Display will show the numbers you pressed in the order you touched them. This example shows 12 minute 30 seconds.



3. Touch POWER LEVEL pad.




The Display will show "P-10"

NOTE: If steps 3 and 4 are omitted, the oven will cook at full power.

Example




4. Touch the Number Pad for the Power level you want.



The Display will show what you touched. This example shows power level 3.



5. Touch the START pad.



The STAGE 1 Indicator Light starts blinking to show that the oven is cooking. The oven lamp will light. The oven will cook at the Power you selected. The Display counts down the time to show how much cooking time is left. When the cooking time ends, you will hear 3 beeps. The oven will stop and the light will go off.


COOKING IN TWO STAGES

For best results, some recipes call for one power level for a certain length of time and another power level for a different length of time. Your microwave oven can be set to change from one to another.

DO THIS...


THIS HAPPENS...


- 
1. Touch the TIME pad.



STAGE 1 Indicator Light will come on.


Example

- 
2. Touch the Number Pads for cooking time you want in the first stage.




The Display will show the numbers you pressed in the order you touched them.
This example shows 13 minutes 40 seconds.


- 
3. Touch the POWER LEVEL pad.



The Display will show "P—10".


Example

- 
4. Touch the Number Pad for the Power level you want in the first stage.



The Display will show what you touched.
This example shows power level 3.

- 
5. Touch the TIME pad a second time.



STAGE 2 Indicator Light will come on.


DO THIS...

THIS HAPPENS...

Example


9 1 0

6. Touch the Number Pads for the cooking time you want in the second stage.



The Display will show the numbers you pressed in the order you touched them. This example shows 9 minutes 10 seconds.

7. Touch the POWER LEVEL pad.




The Display will show "P—10".

Example


8

8. Touch a Number Pad for the Power level you want in the second stage.



The Display will show what you touched. This example shows power level 8.


9. Touch the START pad.



When you touch START, both STAGE 1 & 2 Indicator Lights come on.

STAGE 1 Indicator Light starts blinking to show you that the oven is cooking in the first of two cook stages.

The oven will cook at the Power you selected for STAGE 1.



At end of the first stage, the oven will beep and start the second stage.

The STAGE 1 Indicator Light will go off and the STAGE 2 Indicator Light starts blinking. The Display counts down the time to show you how much cooking time is left in the second stage. When STAGE 2 ends, you will hear 3 beeps.

AUTO DEFROSTING AND COOKING IN TWO STAGES

Some recipes require frozen foods to be thawed before cooking.
This oven can be programmed to automatically defrost foods before cooking.


DO THIS...

THIS HAPPENS...

Example



1. Touch the POULTRY pad.




Selected food item Indicator Light will come on.

Example

(8) (5) (0)


2. Touch the Number Pads for the defrosting weight you want.



The Display will show the numbers you pressed in the order you touched them.
This example shows 850g.



3. Touch the TIME pad.




STAGE 1 Indicator Light will come on.

Example

(2) (5) (1) (0)


4. Touch the Number Pads for the cooking time you want in the first stage.



The Display will show the numbers you pressed in the order you touched them. This example shows 25 minutes 10 seconds.



5. Touch POWER LEVEL pad.



The Display will show "P-10".


DO THIS...

THIS HAPPENS...

Example

①


6. Touch the Number Pad for the Power level you want in the first stage.



The Display will show what you touched.
This example shows power level 1.



7. Touch the **TIME** pad a second time.




STAGE 2 Indicator Light will come on.

Example

⑤ ④ ①


8. Touch the Number Pads for the cooking time you want in the second stage.



The Display will show the numbers you pressed in the order you touched them. This example shows 5 minutes 40 seconds.



9. Touch the **POWER LEVEL** pad.




The Display will show "P—10".

Example

⑧

10. Touch the Number pad for the Power level you want in the second stage.




The Display will show what you touched.
This example shows power level 8.

DO THIS...




1. Touch the **START** pad.

THIS HAPPENS...



When you touch **START**, the Indicator Light of poultry and **STAGE 1** and **2** come on simultaneously. The poultry, Indicator Light starts blinking to show you that oven is cooking in the **AUTO DEFROST** mode.

The Display will counts down the time to show you how much defrosting time is left in the **AUTO DEFROST** mode. When the defrosting time ends, you will hear a beep and the oven will automatically start cooking in the first stage.




The poultry, Indicator Light will go off and **STAGE 1** & **2** Indicator Light will stay on.

STAGE 1 Indicator Light starts blinking.

The oven will cook at the power you selected for stage 1.

The Display will counts down the time to show you how much cooking time is left in the first stage.



The **STAGE 1** Indicator Light will go off and the **STAGE 2** Indicator Light starts blinking. The oven will cook at the power you selected for stage 2. The display will count down the time to show you how much cooking time is left in the second stage. When the second stage ends, you will hear 3 beeps.

AUTO START


Allows you to program cooking to start at a time you select (up to 11 hours and 59 minutes ahead of the present time). The food will automatically start cooking at the desired time.

DO THIS...

THIS HAPPENS...

1. Program desired cooking time and power level as previously instructed.


2. Touch the AUTO START pad.



The AUTO START Indicator and the colon come on and "00:00" is displayed.

Example

3. Enter the desired start time by pressing the numbered pads.



The Display will show the numbers you pressed in the order you touched them. This example shows 11 hours 13 minutes.

4. Touch the START pad.



The present time appears and the cooking program Indicator Light stay on. AUTO START Indicator Light starts blinking and oven light remains off as the oven waits for starting time.

When the selected time arrives, the oven enters into the previously selected cooking function and the oven light turns on. The AUTO START Indicator Light disappears and the next stage Indicator Light begins to blink.

When cooking is completed, you will hear 3 beeps. The oven and Indicator Light turn off and the present time will show in the display window.

NOTE: If oven door is opened, after program has occurred press the start pad again after closing the door so that the oven will start at the programmed time.

TO CHECK THE AUTO START TIME

Once you have correctly programmed the oven for Auto Start, the present time (not the Auto Start time) will appear on the display.

DO THIS...

THIS HAPPENS...



1. Touch the AUTO START pad.

The Programmed Auto Start time will appear on the display for 5 seconds.

ONE MINUTE REPEAT

This is convenient, short cooking program which operates the oven for one minute on HIGH(10) power. If you've touched this pad after ending the stage cook 1 or 2, the oven cooks at the previously selected power level (stage COOK1, 2) for one minute.


DO THIS...

THIS HAPPENS...

Example 1

+1 min

1. Touch PAUSE/CLEAR pad.
2. Touch ONE MINUTE REPEAT pad.




The oven starts automatically and cooks at power level 10 for one minute.

The Display counts down the time and the REPEAT Indicator Light starts blinking.

Example 2

+1 min

1. Touch ONE MINUTE REPEAT pad after ending the stage cook 1 or 2.



The oven starts automatically and cooks at the selected power level stage cook 1 or 2.

The Display counts down the time and the REPEAT Indicator Light starts blinking.


AUTO REHEAT

Designed for reheating a variety of leftover foods. With this control, all you have to do is to enter your food selection. Touch this pad repeatedly for the food you select, then touch START. The oven does the rest automatically.

DO THIS...

THIS HAPPENS...

1. Touch the REHEAT pad.




The AUTO REHEAT Indicator Lights and food category "A-1" is displayed.

Keep pressing this pad to select other food category as shown in the chart below.

CATEGORY	FOOD	WEIGHT	PROGRAMMED TIME (min.)
A-1	Meat Slices	360 g	4:30
A-2	Casseroles	2 Cups (450 g)	4:30
A-3	Soup	290 g	5
A-4	Coffee	1 mug (250 ml)	1:50
A-5	Plated Meals	300 g	4:30


2. Touch the MORE or LESS pad.



The time category "10" is displayed. Keep pressing MORE or LESS pad to select other time category as shown in the chart below. This example shows category "10".

PAD	CATEGORY	COOK TIME
[+] MORE	10	programmed time + 10 sec.
	20	programmed time + 20 sec.
[-] LESS	-10	programmed time - 10 sec.
	-20	programmed time - 20 sec.

3. Touch the START pad.



AUTO REHEAT Indicator Light starts blinking and cooking time is displayed.

When the cooking time ends, you will hear 3 beeps.

NOTE: If step 2 is omitted, the oven will cook at the programmed time.

MORE, LESS PADS

These pads only work during AUTO REHEAT mode.
When using the MORE or LESS pad, you see page 18.

TO STOP THE OVEN WHILE IT IS OPERATING

1. Press the PAUSE/CLEAR pad once.
 - You can restart the oven by touching START.
 - Touch PAUSE/CLEAR pad once more to erase all instructions except for memory data.
 - You must enter in new instructions.
2. Open the door.
 - You can restart the oven by touching START.

NOTE: Oven stops operating when the door is opened.

PRECAUTIONS FOR DISASSEMBLY AND REPAIR

—Cautions to be observed when trouble shooting.

Unlike many other appliances, the microwave oven is high-voltage, high-current equipment. It is completely safe during normal operation. However, carelessness in servicing the oven can result in an electric shock or possible danger from a short circuit. You are asked to observe the following precautions carefully.

- (1) Always remove the power plug from the outlet before servicing.
- (2) Use an insulated screwdriver and wear rubber gloves when servicing the high voltage side.
- (3) Discharge the high voltage capacitor before touching any oven components or wiring.


1. Check the grounding.

Do not operate on a two wire extension cord. The microwave oven is designed to be used when grounded.

It is imperative, therefore, to make sure it is grounded properly before beginning repair work.

2. Warning about the electric charge in the high voltage capacitor.

For about 30 seconds after the operation stops, electric charge remains in the high voltage capacitor. When replacing or checking parts, short oven chassis and the negative high terminal of the high voltage capacitor by using a properly insulated screw driver to discharge.



- (4) When the 8 Amp fuse is blown out due to the operation of the monitor switch; replace primary, secondary interlock switch and monitor switch. Refer to next page for the necessary adjustment.
- (5) After repair or replacement of parts, make sure that the screws are properly tightened and all electrical connections are tightened.
- (6) Do not operate without cabinet.

CAUTION: Servicemen should remove their watches whenever working close to or repairing the magnetron.

WARNING: When servicing the appliance, need a care of touching or replacing high potential parts because of electrical shock or exposing microwave. These parts are as follows—H.V. Transformer, Magnetron, H.V. Capacitor, H.V. Diode.

MEASUREMENT

1. Microwave Output Power

1-1. Standard Method


Microwave output power can be checked by indirectly measuring the temperature rise of a certain amount of water exposed to the microwave as directed below.

- 1) Microwave power output measurement is made with the microwave oven supplied at rated voltage and operated at its maximum microwave power setting with a load of $1,000 \pm 5\text{cc}$ of potable water.
- 2) The water is contained in a cylindrical borosilicate glass vessel having a maximum material thickness of 3 mm and an outside diameter of approximately 190 mm.
- 3) The oven and the empty vessel are at ambient temperature prior to the start of the test.
The initial temperature of the water is $10 \pm 2^\circ\text{C}$ ($50 \pm 3.6^\circ\text{F}$).
It is measured immediately before the water is added to the vessel. After addition of the water to the vessel, the load is immediately placed on the center of the shelf which is in the lowest normal position. (Fig. 1).
- 4) Microwave power is switched on.
- 5) Heating time should be exactly 46 seconds.
Heating time is measured while the microwave generator is operating at full power.
The filament heat-up time for magnetrons is not included.
- 6) The initial and final water temperatures are selected so that the maximum difference between the ambient and final water temperatures is 5K.
- 7) The microwave power output P in watts is calculated from the following formula:

$$P = 4187 \times \Delta T / t$$

- ΔT is actual temperature rise.
- t is the heating time.

The power measured should be $900\text{W} \pm 10\%$.



CAUTION:

1. Water load should be measured exactly to 1 liter.
2. Input power voltage should be exactly 230 volts as specified.
3. Ambient temperature should be $20 \pm 2^\circ\text{C}$ ($68 \pm 3.6^\circ\text{F}$)

MICROWAVE RADIATION TEST

WARNING

- Make sure to check the microwave leakage after repair or adjustment.
- Always, start measuring of an unknown field to assure. Safety for operating personnel from microwave energy.
- Do not place your hands into any suspected microwave radiation field unless the safe density level is known.
- Care should be taken not to place the eyes in direct line with the source of microwave energy.
- Slowly approach the unit under test until the radiometer reads an appreciable microwave leakage from the unit under the test.


Procedure

- A) Prepare Microwave Energy Survey Meter, 600cc glass breaker, glass thermometer 100°C or 212°F.
- B) Pour 275cc \pm 15cc of tap water initially at 20 \pm 5°C (68 \pm 9°F) in the 600cc beaker with a inside diameter of approx. 8.5cm.
- C) Place it at the center of the tray and set it in a cavity.
- D) Close the door and operate the oven.
- E) Measure the leakage by using microwave energy survey meter with dual ranges, set to 2,450 MHz.
 - Measured radiation leakage must not exceed the values prescribed below.
 - Leakage for a fully assembled oven with door normally closed must be less than 4mW/cm².


—When measuring the leakage, always use the 2 in (5cm) space cone with probe. Hold the probe perpendicular to the cabinet, door. Place the space cone of the probe on the door, cabinet, door seam, along the seam, the door viewing window, the exhaust air vents, the suction air vents.

—Measuring should be in a counter-clockwise direction at a rate of 1 inch/sec. If the leakage of the cabinet door seam is unknown, move the probe more slowly.

—When measuring near a corner of the door, keep the probe perpendicular to the areas making sure the probe end at the base of the cone does not get closer than 2 inches from any metal.
If it does, erroneous reading may result.



KOR-804M WIRING DIAGRAM



CIRCUIT DESCRIPTION

Refer to the "WIRING DIAGRAM" on page 23.

MICROWAVE COOKING

TIME COOKING

1. When the food is placed inside the oven door is closed.

- 1) The low voltage transformer supplies the necessary voltage to the touch control circuit when the power cord is plugged in.
- 2) The contacts of the interlock monitor switch open.
This switch creates short circuit to below 8A fuse and stop magnetron oscillation when door is opened during operation under abnormal condition (i.e. both the contacts of primary interlock switch do not open the circuit).
- 3) The contact of primary interlock switch close the primary circuit.

2. When cooking cycle, power and time are set by touching the function pads and the desired numerical pads.

- 1) Cooking the function indicating bar located on the digital light to indicate that function have been set.
- 2) The time you set appears in the display window.
- 3) The touch control circuit memorizes the cooking program you set.

3. When the start pad is touched.

* The RELAY "1" and "2" are controlled by the touch control circuit.

- 1) 230VAC is applied to the high voltage transformer through the contacts of RELAY "1" (See page 23)
- 2) Fan motor starts rotating and cools the magnetron by blowing the air coming from the intake on the rear back hole.
- 3) The oven lamp lights the inside of the oven.
- 4) Indicator light turns on to indicate function operation. Cooking time starts count down.
- 5) 3.3 Volts AC is generated from the filament winding of the high voltage transformer. This filament voltage is applied to the magnetron to heat the magnetron filament through two noise preventing choke coils.
- 6) A high voltage of 2000 Volts AC is generated in the secondary of high voltage transformer and this secondary voltage is increased by the action of the diode and the charging of the high voltage capacitor. This resultant DC voltage is then applied to the anode of the magnetron. As shown in Fig. 2 the first half cycle of the high voltage produced in the high voltage transformer secondary charges the high voltage capacitor. Current flow is in the direction of the dotted-line during the second half cycle, the voltage produced by the transformer secondary, and the charge of the high voltage capacitor are combined and applied to the magnetron as shown by the solid line so that oscillations begins.

The disturbance wave generated by the magnetron is prevented by the choke coils filter capacitors and the magnetron's shielded case so that TV and Radio programs are not impaired by noise.




Fig. 2

The touch control circuit controls the ON-OFF time of RELAY "1" in order to vary the output power of the microwave oven from "power level 1" to "Full (100%) power". The relation between indications on the control panel and the output of the microwave oven is as shown in Fig. 3.

POWER LEVEL	OUTPUT POWER AGAINST FULL POWER	RELAY "1" TURN ON, OFF TIME
1	3/29 (10%)	ON 3S OFF
2	5/29 (17%)	ON 5S OFF
3	8/29 (28%)	ON 8S OFF
4	11/29 (38%)	ON 11S OFF
5	14/29 (48%)	ON 14S OFF
6	17/29 (59%)	ON 17S OFF
7	20/29 (69%)	ON 20S OFF
8	23/29 (79%)	ON 23S OFF
9	26/29 (90%)	ON 26S OFF
10	29/29 (100%)	ON 29S OFF

Fig. 3

AUTO WEIGHT DEFROST CYCLE

When auto defrost is selected and the desired defrosting time is chosen, the automatic cycle divides the defrosting time into 5 periods of alternating defrost and stand times, by cycling on and off.

4. When the door is opened during cooking.

- 1) The primary interlock switch is opened to cut off primary voltage to the high voltage transformer to stop microwave oscillation.
- 2) The secondary interlock switch is opened to give the door open information to touch control circuit. The contacts of the RELAY "1" and "2" open, the display stops counting down.
- 3) Fan motor and turn table motor stop rotating.
- 4) The oven lamp turns off.
- 5) As soon as the door is opened, the interlock monitor switch contacts close and creates the short circuit.
- 6) If the contacts of primary interlock switch malfunction the 8A fuse blows open due to the large current surge caused by the short circuit activation, and this in turn stops magnetron oscillation (Fig. 1).

5. When the PAUSE/CLEAR pad is touched during cooking.

- 1) The touch control circuit cuts the voltage supplied to the RELAY "1" coil causing the magnetron to stop oscillation.
- 2) The RELAY "2" turns off.
- 3) The display will show the time of day. If you didn't set the clock, the display will show a colon.
- 4) The Oven lamp turns off.
- 5) Fan motor and turn table motor stop rotating.

INTERLOCK MECHANISM

The door lock mechanism is a device which has been specially designed to completely eliminate microwave radiation when the door is opened during operation, and thus to perfectly prevent the danger resulting from the leakage of microwave.


(1) Primary interlock switch

When the door is closed, the hook locks the oven door.

If the door is not closed properly, the oven will not operate.

When the door is closed, the hook pushes the lever downward.


The lever presses the button of the primary interlock switch to switch it 'ON'.



Adjustment 1.


When the door is closed, the switch button is pushed by the hook.

The movement of the switch button should exceed 1.2mm measured at the top of the button.



(2) Secondary interlock switch and interlock monitor switch

When the door is closed, the hook pushes the lever forward, and pushes the Latch Lever downward the lever presses the button of the interlock monitor switch to bring it under 'OFF' condition. The Latch Lever presses the button on the secondary interlock switch to bring it under 'ON' condition.



Adjustment 2.

Interlock monitor switch

When the door is closed, the interlock monitor switch should be opened before other switches close. When the door is opened, the interlock monitor switch should be closed after other switches open.

Secondary interlock switch

The movement of the switch button should exceed 1.2mm measured at the top of the button.

(3) Adjustment step:

- Loosen the two mounting screws.
- Adjust the interlock switch assembly position.
- Confirm the gap (1.2mm) described above.
- Completely tighten the two mounting screws.

NOTE: Microwave emission test should be performed after adjusting interlock mechanism. If the microwave emission exceed 4mW/cm^2 , readjust interlock mechanism.

(4) Interlock switch replacement


Whenever safety interlock switch are replaced:

- Refer to the following diagram.
- Perform the electrical continuity check of interlock switches and microwave emission test mentioned in this manual.

DISASSEMBLY AND ASSEMBLY


1. To remove cabinet.

Remove four screws on cabinet back.




2. To remove door assembly.

- (1) Remove four bolts ①, nuts ② which secure top hinge and under hinge stopper, respectively.
- (2) Remove the top door hinge ③ and under hinge stopper ④.
- (3) Remove door assembly ⑤.
- (4) Reverse the above for reassembly taking case to replace fixing glue.




3. To remove door parts.




- (1) Remove the out plate ① and door frame ②.
- (2) Remove the microwave absorber ③ and film ④.
- (3) Remove a spring two hook pins a hook lever ⑦ and two hooks ⑧, ⑨.
- (4) The door weld assembly ⑩.
- (5) Reverses the above steps for reassembly.

4. Method to reduce the gap between the door seal and the oven front surface.

- (1) To reduce gap located on part 'A'.
 - 1) Loosen two bolts and nuts. On top door hinge stopper, then push the door to contact the door seal to oven front surface.
 - 2) Tighten two bolts and nuts.




- (2) To reduce gap located on part 'B'.
 - 1) Loosen two bolts and nuts on under hinge stopper, then push the door to contact the seal to oven front surface.
 - 2) Tighten two bolts and nuts.
- (3) To reduce gap located on part 'C'. (See Fig. A)
 - 1) Remove the cabinet.
 - 2) Loosen a screw on interlock switch assembly located bottom of oven body.
 - 3) Draw the interlock switch assembly inward as possible to engage with hook on the door bottom.
 - 4) Tighten a screw.
- (4) To reduce gap located on part 'D' (See Fig. B)
 - 1) Remove the cabinet.
 - 2) Loosen a screw on interlock switch assembly located top of oven body.
 - 3) and (4) are same as step (3).




NOTE: A small gap may be acceptable if the microwave leakage does not exceed 1mW/cm².

5. To remove control panel assembly.

- (1) Disconnect two connectors and two terminals on the printed circuits board assembly and remove a screw ⑧ holding the grounding ring terminal ⑨ of P.C.B. assembly, which secured over front.
- (2) Remove two screws holding control panel assembly to the oven front. At the same time, draw forward the control panel assembly from oven front.
- (3) Remove the push lever ③.
- (4) Remove the two screws ⑥.
- (5) Remove push button ④ and button spring from control panel ⑤.
- (6) Reverse the above steps for reassembly.




NOTE: Do not attempt to remove membrane key board ② except for replacement.




6. To remove high voltage capacitor.

- (1) Remove a screw ① which secure the grounding ring terminal ② of diode and capacitor holder ④.
- (2) Remove a screws ⑤ which secure the capacitor holder ④.
- (3) Remove capacitor holder ④ with capacitor ③.
- (4) Reverse the above steps for reassembly.




High voltage circuit wiring





7. To remove magnetron.

- (1) Remove a screw ① which secure the wind guide.
- (2) Remove the wind guide ②.
- (3) Remove two screws ③ which secure the duct.
- (4) Remove the duct ④.
- (5) Remove four nuts ⑤ which secure the magnetron ⑥.
- (6) Remove the magnetron.
- (7) Remove two screws ⑦ which the thermostat ⑧.
- (8) Remove the thermostat.
- (9) Reverse the above steps for reassembly.




CAUTION: Never install the magnetron without the metallic gasket plate which is packed with each magnetron to prevent microwave leakage. Whenever repair work is carried out on magnetron, check the microwave leakage. It shall not exceed $4\text{mW}/\text{cm}^2$ for assembled oven with door normally closed..




8. To remove fan motor assembly and wind guide.

- (1) Remove three screws ①.
- (2) Remove power cord bushing bracket ⑧.
- (3) Remove wind guide ②.
- (4) Remove three screws ③ holding the fan motor bracket ⑤.
- (5) Remove fan ④.
- (6) Remove three screws ⑦ and separate the bracket ⑤ from the fan motor ass'y ⑥.
- (7) Reverse the above for reassembly.



9. To remove transformer.

- (1) Remove four screws ①, holding transformer.
- (2) Remove the transformer ②.
- (3) Reverse the above steps for reassembly.



TROUBLE SHOOTING GUIDE


Following the procedures below to check if the oven is defective or not.

1. Check grounding before checking trouble.
2. Be careful of the high voltage circuit.
3. Discharge the high voltage capacitor. (see page 20)
4. When checking the continuity of switches or of the high voltage transformer, disconnect one lead wire from these parts and then check continuity with the AC plug removed. To do otherwise may result in false reading or damage to your meter.
5. Do not touch any part of the circuitry on the touch control circuit since static electric discharge may damage this control panel.
Always touch yourself to grounding parts while working on this panel to discharge any static charge built up in your body.


First of all, operate the microwave oven according to the correct operation procedures described on page 8~19 in order to find the exact cause of any troubles.

TROUBLE 1. The following visual conditions indicate a probable defective P.C.B. assembly or membrane switch assembly.

1. Incomplete segments.
(A) Segments missing.
(B) Partial segments missing.
(C) Digit flickering other than normal fluorescent slight flickering.
(D) "1:00" does not display when power is on.
2. A distinct change in the brightness of one or more numbers in the display.
3. One or more digits in the display are not on when they should be.
4. Display indicates a number different from one touched.
5. For example, touch 5 and 3 appears in the display.
6. Specific numbers (for example 2 or 3) will not display when the panel is touched.
7. Display does not count down or up with time cooking or clock operation.
8. The oven programmable and cooks normally but no display shows.
9. Display obviously jumps in time while counting down.
10. Display counts down noticeably too fast while cooking.
11. Display can not shift from the first stage cooking to the third stage cooking while 3 phase cooking (including AUTO WEIGHT DEFROST).
12. Display does not show the time of day when dear pad is touched.
13. The oven lamp and fan motor and turn table motor do not stop although cooking is finished. Check if the RELAY "2" contacts close if they are close, replace touch control circuit.



(TROUBLE 2) Digital readout display does not show programming, even if the memberane key-board is programmed by touching proper pads.



NOTE: Before following the particular steps listed above in the trouble shooting guide for the mem-brane keyboard, failure, please check for the continuity of each wire harness between the membrane keyboard and control box assembly.

MEMBRANE KEYBOARD CHECK PROCEDURE

1. Check the pad termination order and nomenclature.




Fig. 4

2. Type of encoding and pad names.




Fig. 5 Key Matrix


The membrane keyboard consists of 24 keys whose configurations are described above and provide 10 pad terminations to be connected to the touch control circuit as Fig. 4.

3. Key check procedure.

To determine if the membrane keyboard is defective or not, check the continuity of each pad (Key) contacts with a multimeter.

1) MORE	pad : Between D and I	13) MEAT	pad : Between A and I
2) LESS	pad : Between E and I	14) 6	pad : Between C and F
3) START	pad : Between E and F	15) 7	pad : Between B and J
4) FISH	pad : Between C and I	16) 8	pad : Between C and J
5) POULTRY	pad : Between B and I	17) 9	pad : Between D and J
6) ONE MINUTE REPEAT	pad : Between D and G	18) 0	pad : Between E and J
7) PAUSE/CLEAR	pad : Between D and F	19) 1	pad : Between G and A
8) POWER LEVEL	pad : Between C and H	20) 2	pad : Between G and B
9) CLOCK	pad : Between E and H	21) 3	pad : Between C and G
10) AUTO REHEAT	pad : Between A and H	22) 4	pad : Between F and A
11) AUTO START	pad : Between E and G	23) 5	pad : Between B and F
12) AUTO DEFRSOT	pad : Between J and A	24) TIME	pad : Between D and H

(TROUBLE 3) Oven does not operate at all; Display window does not display any figures and any inputs can not be accepted.



NOTE 1: All these switches must be replaced at the same time, please refer to page 27 and 28 for adjustment instructions.

Condition	Check	Result	Cause	Remedy
Outlet has proper voltage Fuse does not open	Check continuity of oven thermostat	No Continuity	Defective oven thermostat.	Replace
	Check continuity of power supply cord.	No Continuity	Open power supply cord	Replace
		Normal	Defective touch control circuit	Replace

(TROUBLE 4) Display shows all figures selected, but oven does not start cooking, even though desired program and time are set and start pad is tapped.

Condition	Check	Result	Cause	Remedy
Turn table motor fan motor and oven lamp do not turn on	Check continuity of primary interlock switch	No Continuity	Malfunction of Primary interlock switch	Adjust or replace
	Check continuity of secondary interlock switch.	No continuity	Malfunction of secondary interlock switch	Adjust or replace
	Check D.C. voltage being supplied to RELAY "2"	0V	Defective touch control circuit	Replace
		Approx. 12V DC	Faulty contacts of RELAY "2" or open relay coil	Replace


Condition	Check	Result	Cause	Remedy
Turn table motor, fan motor and oven lamp turn on for a second when the start pad is tapped	Check continuity of primary winding of high voltage transformer and touch control circuit	No Continuity	Open winding	Replace
		Normal	Defective touch control circuit	Replace

(TROUBLE 5) No microwave oscillation even though fan motor rotates.

Condition	Check	Result	Cause	Remedy
No microwave oscillation	Check continuity of connecting wire of magnetron.	Continuity		
	Check the isolation of filament winding of high voltage transformer	No Good	Defective high voltage transformer	Replace
		Good	Defective magnetron	Replace
		No Continuity		
	Check continuity of filament of magnetron.	No Continuity	Defective magnetron	Replace
		Continuity		
	Check continuity of filament terminal of high voltage transformer	No Continuity	Defective high voltage transformer	Replace
		Continuity		
	Check the diode for continuity in the reverse and normal directions	Continuity in the reverse direction	Defective high voltage diode	Replace

(TROUBLE 6) Microwave output power is low.

First of all, check if output power is really low following "measurement of the microwave output power" on page 21.



NOTE 2: The following chart shows the timing periods of the RELAY "1".

POWER	RELAY "1" ON TIME	RELAY "1" OFF TIME
1	3 (Seconds)	26 (Seconds)
2	5	24
3	8	21
4	11	18
5	14	15
6	17	12
7	20	9
8	23	6
9	26	3
10 (Full)	29	0


COMPONENT TEST PROCEDURE

CAUTION:

1. High voltage is present at the high voltage terminal of the high voltage transformer during any cook cycle.
2. It is neither necessary nor advisable to attempt measurement of the high voltage.
3. Before touching any oven components or wiring, always unplug the oven from its power source and discharge the capacitor (see page 20).

1. High voltage transformer

- (A) Remove connections from the transformer terminals and check continuity.
- (B) Normal readings should be as follows:
 Secondary winding Approx. $94\Omega \pm 5\%$
 Filament winding Approx. 0Ω
 Primary winding Approx. 1Ω



2. High voltage capacitor

- (A) Check continuity of capacitor with meter on the highest OHM scale.
- (B) A normal capacitor will show continuity for a short time, and then indicate $9M\Omega$ once the capacitor is charged.
- (C) A shorted capacitor will show continuous continuity.
- (D) An open capacitor will show constant $9M\Omega$.
- (E) Resistance between each terminal and chassis should be infinite.

3. High voltage diode


- (A) Isolate the diode from the circuit by disconnecting the leads.
- (B) With the ohmmeter set on the highest resistance scale, measure the resistance across the diode terminals.

Reverse the meter leads and again observe the resistance reading. Meter with 6V, 9V or higher voltage batteries should be used to check the front-to-back resistance of the diode, otherwise an infinite resistance may be read in both directions. A normal diodes resistance will be infinite in one direction and several hundred $K\Omega$ in the other direction.

4. Magnetron

For complete magnetron diagnosis, refer to "Measurement of the microwave output power" (Page 14) continuity checks can only indicate and open filament or a shorted magnetron. To diagnose for an open filament or shorted magnetron.

- (A) Isolate magnetron from the circuit by disconnecting the leads.
- (B) A continuity check across magnetron filament terminals should indicate one ohm or less.
- (C) A continuity check between each filament terminal and magnetron case should read open.



CAUTION:

Never install the magnetron without the metallic gasket plate which is packed with each magnetron to prevent microwave leakage. Whenever repair work is carried out on magnetron, check the microwave emission, check the microwave emission. It shall not exceed $4mW/cm^2$ for a fully assembled oven with door normally closed.

5. Fuse


If the fuse in the primary monitor switch circuit is blown when the door is opened, check the primary and secondary interlock switch and monitor switch before replacing the blown fuse. In case the fuse is blown by an improper switch operation, replace the defective switch and fuse at the same time. Replace just the fuse if the switches operate normally.

REPLACE BLOWN FUSE WITH 8 AMPERE FUSE.
FUSE TYPES: SAMWHA 65M FUSE, OR BUSSMAN ABC-8 1 OR LITTLE H314008.

6. Interlock switches

- You can test continuity of safety interlock and monitor switch by using ohmmeter.
- The switch operation is checked by zero/unlimited.
The meter should indicate zero resistance.
- The sequence of check is interlock monitor switch, primary and secondary interlock switches check.


1) In case of interlock monitor switch check.



Condition

- 1) Door is opened.
- 2) NC terminal of the monitor switch disconnected.


2) In case of primary interlock switch check.



Condition

- 1) Door is closed.
- 2) No terminal of the monitor switch disconnected.

3) In case of secondary interlock switch check.



Condition

- 1) The same as primary interlock switch check.

PRINTED CIRCUIT BOARD


1. CIRCUIT CHECK PROCEDURE

1) Low Voltage Transformer (DMR-101FS) Check.

The low voltage transformer is located on the P.C.B.

Measuring condition: Input voltage: 230V

Frequency: 50Hz



Terminal	Voltage	LOAD	NO LOAD
N—O		30V	45V
K—M		2.6V	3.5V
A—B		10V	15V

NOTE 1: Secondary side voltage of the low voltage transformer changes in proportion to fluctuation of power source voltage.

NOTE 2: The allowable tolerance of the secondary voltage is within $\pm 5\%$ of nominal voltage.

2) Voltage Check

Key check point (MICOM PIN)

NO.	CHECK POINT	REMARK
1	PIN 21 or 30	- 5VDC
2	PIN 16	- 24VDC
3	PIN 35	
4	PIN 31 or 32	
5	DP2 PIN 1 & 16	2.0VAC (DISPLAY FILAMENT VOLTAGE)

CHECK METHOD

NO.	MEASURE POINT Fig. 6	WAVE FORM	REMARK
1	MP 1	- 14V DC	Replace BD1
2	MP 2	- 5V DC	Replace VL1
3	MP 3	- 12V DC	Replace R15, EC2
4	MP 4	- 24V DC	Replace R17, ZD2

NOTE: Each measure point must be measured with GND points.





Fig. 7 Measure Point

3) Display problems

NO.	CAUSE	MEASUREMENT	RESULT	REMEDY
1	Poor contact between P.C.B. and display filament.	1. Check the voltage of PIN 1 & PIN 16.	2.0 VAC	Fix the PIN 1 & 16 on the P.C.B.
2	Defective display	Refer to "The display trouble shooting data" below.		Replace P.C.B. assembly.
3	Loss of vacuum in the display.	<p>white spot</p> 	White spot is generated on the display	Replace P.C.B. assembly

The display trouble shooting data


TROUBLE	DISPLAY NAME & PIN NO.	MICOM OUTPUT IN PIN NO.
1ST STAGE, PAUSE don't come on.	GRID1 (G1), 11	8
2ND STAGE, AUTO START don't come on.	GRID2 (G2), 10	9
MEAT, AUTO DEFROST don't come on.	GRID3 (G3), 9	10
POULTRY, AUTO REHEAT don't come on.	GRID4 (G4), 8	11
FISH, g don't come on.	GRID5 (G5), 7	12
SEGMENT "a" doesn't come on from G1 to G5.	SEGMENT a, 15	20
SEGMENT "b" doesn't come on from G1 to G5.	SEGMENT b, 14	22
SEGMENT "c" doesn't come on from G1 to G5.	SEGMENT c, 13	23
SEGMENT "d" doesn't come on from G1 to G5.	SEGMENT d, 12	17
SEGMENT "e" doesn't come on from G1 to G5.	SEGMENT e, 5	18
SEGMENT "f" doesn't come on from G1 to G5.	SEGMENT f, 3	19
SEGMENT "g" doesn't come on from G1 to G5.	SEGMENT g, 4	24
STAGE1, STAGE2, MEAT, POULTRY, FISH	UPPER BAR i, 6	7
PAUSE, AUTO START, g, AUTO REHEAT, AUTO DEFROST don't come on.	LOWER BAR h, 2	6

4) When there is no microwave oscillation.

(1) When touching "START" pad, oven lamp does not turn on.

Fan motor and turntable motor do not rotate, but cook indicator in display comes on.

*Cause: RELAY "2" does not operate.




CHECK METHOD

STAGE	POINT	A	B
RELAY "2" ON		-5VDC	GND
RELAY "2" OFF		GND	-12VDC

(2) When touching "START" pad, oven lamp turns on.

Fan motor and turntable motor rotate and cook indicator in display comes on.


*Cause: RELAY "1" does not operate.



CHECK METHOD

STAGE	POINT	A	B
RELAY "1" ON		-5VDC	GND
RELAY "1" OFF		GND	-12VDC

5) When the door is opened during operation, the Count down timer does not stop.




CHECK METHOD

STAGE	POINT	A	B
1) DOOR OPENED		OPEN	-5VDC
2) DOOR CLOSED		CLOSE	GND

CHECK NO.	METHOD	REMEDY
1	Check the state (ON, OFF) of the secondary Interlock switch by resistance measurement.	Replace secondary interlock S/W

6) When the digital clock does not operate properly.




POINT	WAVEFORM
A	
B	
C	


If clock does not keep exact time, you must check Diode D8, transistor Q5.

2. Component Information


1) Voltage regulator




2) Transistor (PNP Type)



3) Diode and zener diode



3. Printed Wiring Borad




4. P.C.B. LOCATION NO.

NO.	NAME	SYMBOL	TYPE NO.	REMRAK
1	DIGITRON	DP2	FG412MIC	
2	IC MICOM	IC1	KOR—804M	
3	P.C.B.	M113	M113	
4	VOLTAGE REGULATOR	VL1	MC7905	
5	R-ARRAY	RA1	RGLD5X104J	
6	C-ARRAY	CA1	5B102M	
7	TRANSISTOR	Q1	KTA562TMY	
8	TRANSISTOR	Q2	KTA562TMY	
9	TRANSISTOR	Q3	KTA562TMY	
10	TRANSISTOR	Q4	KTM562TMY	
11	TRANSISTOR	Q5	KTA562TMY	
12	DIODE	D1	1N4148	
13	DIODE	D2	1N4148	
14	DIODE	D3	1N4148	
15	DIODE	D4	1N4148	
16	DIODE	D5	1N4148	
17	DIODE	D6	1N4148	
18	DIODE	D7	1N4148	
19	DIODE	D8	1N4148	
20	DIODE	D9	1N4002A	
21	DIODE-Z	ZD1	MTZ 3.9V, 1/2W	
22	DIODE-Z	ZD2	MTZ 24VD, 1/2W	
23	DIODE-Z	ZD3	MTZ 4.7V 1/2W	
24	BRIDGE DIODE	BD1	3N247	
25	BUZZER	BZ1	BS-20AS	
26	RESONATOR	CR1	CSA 4.00MG	
27	SW RELAY	CR1	G5J-1-TP-12V	
28	SW RELAY	RY2	VG12TM	
29	CAPACITOR	C1	30pF, 50V	
30	CAPACITOR	C2	30pF, 50V	
31	CAPACITOR	C3	104, 50V	CERAMIC
32	CAPACITOR	C4	104, 50V	CERAMIC
33	CAPACITOR	C5	0.33 μ F, 50V	CERAMIC
34	CAPACITOR	C6	104, 50V	CERAMIC
35	CAPACITOR	C7	0.33 μ F, 50V	CERAMIC
36	CAPACITOR	C8	104, 50V	CERAMIC
37	CAPACITOR	C9	104, 50V	CERAMIC
38	CAPACITOR	EC1	10 μ F, 50V	ELECTROLYTIC
39	CAPACITOR	EC2	1000 μ F, 25V	ELECTROLYTIC
40	CAPACITOR	EC3	220 μ F, 50V	ELECTROLYTIC

P.C.B. LOCATION NO.


NO.	NAME	SYMBOL	TYPE NO.	REMRAK
41	RESISTOR	R1	10 Ω , 1/4W	
42	RESISTOR	R2	1K, 1/4W	
43	RESISTOR	R3	10K, 1/4W	
44	RESISTOR	R4	100 Ω , 1/4W	
45	RESISTOR	R5	100K, 1/4W	
46	RESISTOR	R6	4.7K, 1/4W	
47	RESISTOR	R7	10K, 1/4W	
48	RESISTOR	R8	4.7K, 1/4W	
49	RESISTOR	R9	4.7K, 1/4W	
50	RESISTOR	R10	4.7K, 1/4W	
51	RESISTOR	R11	10K, 1/4W	
52	RESISTOR	R12	10K, 1/4W	
53	RESISTOR	R13	4.7K, 1/4W	
54	RESISTOR	R14	10K, 1/4W	
55	RESISTOR	R15	4.7 Ω , 1/4W	
56	RESISTOR	R16	10K, 1/4W	
57	RESISTOR	R17	1K, 1/4W	
58	RESISTOR	R18	4.7 Ω , 1/4W	
59	TRANS POWER	TF1	DMR-101FS	
60	CONNECTOR	CN1	86749-910	
61	CONNECTOR	CN2	5267-02A	
62	CONNECTOR	CN5	YW396-5A	
63	VARISTOR	VR1	TNR15G561K	
64	EARTH-WIRE	EJ1	UL1015 AWG16	
65	SPONGE FIP	SPONGE	T3 \times 12 \times 20	

5. P.W.B. Circuit Diagram




EXPLODED AND PARTS LIST

1. Door Assembly



NO.	PART NAME	REMARK	PART CODE	Q'TY
1	Barrier-Screen *0	Acryl 1.5t	3517000700	1
2	Frame Door	ABS	3512200300	1
3	Absorber Micro	SFA1	441G440041	1
4	Plate Inner	PE 0.125t	441P741302	1
5	Spring Hook	PW1 MFZN 10	441G448071	1
6	Hook Pin	SWRM3	4413A40052	2
7	Hook Lever AS	SBHG1 T1.2	441G448052	1
8	Hook top	POM	441G448052	1
9	Hook Under	POM	441G440021	1
10	Door Painting AS	Painted Door	3511700200	1

2. Control Panel Assembly



NO.	PART NAME	PART CODE	Q'TY
1	Control Panel	3616701600	1
2	Membrane	3518501200	1
3	Push Lever	4413A30054	1
4	Door Button	3516900900	1
5	Button Spring	441G430171	1
6	Tapping Screw	7112400811	3
7	P.C.B. Ass'y	3516703700	1
8	Tapping Screw	7128401611	2

This is a detailed exploded view diagram of a refrigerator, showing the relationship between various components. The diagram includes the following parts and their assembly sequence:

- Exterior Panels:** The main body panels (1, 2, 3) are shown at the bottom left, with the top panel (1) featuring a handle (2) and a hinge (3).
- Door Assembly:** The door panel (60) is shown at the bottom right, with its internal components including the door handle (54), door hinge (55), and door seal (56).
- Internal Components:** The internal frame (4) is shown in the center, with various internal parts like the evaporator (5), condenser (6), and compressor (7) shown in exploded view.
- Refrigerator Compartment:** The refrigerator compartment (10) is shown in the middle, with its internal components including the evaporator (11), condenser (12), and compressor (13).
- Freezer Compartment:** The freezer compartment (14) is shown at the top, with its internal components including the evaporator (15), condenser (16), and compressor (17).
- Accessories:** Various accessories like the ice maker (18), water filter (19), and defrost timer (20) are shown in exploded view.

The diagram uses dashed lines to indicate the assembly path and alignment of the parts. The parts are numbered 1 through 80, providing a clear reference for identification.

NO.	PARTS NAME	PART CODE	QTY
1	CABINET	2110130117	1
2	SCREW TAPPING 4×8 MFZN	7112400811	2
3	SCREW TAPPING 4×8 TB-W	7S312B4081	2
4	SCREW SPECIAL	4414F92C50	1
5	SPACER	4414A54270	1
6	POWER CORD ASS'Y	441BM699F0	1
7	NOISE FILTER	441P470G01	1
8	SCREW TAPPING	7181401211	2
9	SCREW TAPPING T1 TRS	7112400811	2
10	SCREW TAPPING	7S312B4081	1
11	SCREW TAPPING	7S312B4081	1
12	SCREW TAPPING	7112400811	1
13	SCREW TAPPING	7112400811	1
14	BKT CORD BUSHING	441Q620050	1
15	SCREW TAPPING	7128401211	2
16	GUIDE WIND	441DA14700	1
17	SCREW TAPPING	7112400811	1
18	NUT HEX	7S67W50X1	4
19	MAGNETRON	3518000100	1
20	THERMOSTAT MAGNETRON	4418F67040	1
21	SCREW TAPTITE	7279300611	2
22	MOTOR FAN	441CZ15010	1
23	FAN	441Q826020	1
24	SCREW TAPPING	7112400811	2
25	GUIDE AIR	3512500500	1
26	LAMP	4417B13010	1
27	SCREW TAPPING	7142401011	1
28	SCREW TAPPING	7S312B4081	1
29	SCREW TAPPING	7621401611	2
30	WASHER TOOTHED	7402205011	2
31	LEVER PIVOT	4418D18021	1
32	LOCK	4418J18011	1
33	SWITCH MICRO	4414A66710	2
34	SWITCH MONITOR	4415A17351	1
35	LOCK LEVER	4413A17032	1
36	SCREW TAPPING	7142400811	1
37	SCREW TAPPING	7142400811	1
38	WASHER TOOTHED	7402205011	1
39	HOLDER CAPACITOR	441Q827032	1
40	CAPACITOR H.V.	4415T66300	1
41	DIODE H.V.	441A266420	1
42	TRANS H.V.	3518100400	1

NO.	PARTS NAME	PART CODE	QTY
43	FOAM TRANS	3517300200	1
44	SCREW TAPTITE FLAN	7277501611	4
45	SCREW TAPPING	7112400811	7
46	SCREW TAPPING	7121401211	4
47	FOOT	4418D04041	4
48	PUSH LEVER	4413A30054	1
49	P.C.B ASS'Y	3516703700	1
50	SCREW TAPPING	7128401611	2
51	SCREW TAPPING	7181401211	2
52	BUTTON SPRING	441G430171	1
53	MEMBRANE SWITCH	3518501200	1
54	BUTTON	3516900900	1
55	CONTROL PANEL	3516701600	1
56	SCREW TAPPING	7111400811	1
57	MOTOR TRAY	441CZ17010	1
58	SPECIAL WASHER TEFRON	3516000200	1
59	COUPLER	4413A14032	1
60	DOOR ASS'Y	3511700100	1
61	BOLT HEX	7650501611	2
62	NUT HEX	7S62W50X1	2
63	WASHER NYLON	4413A01010	2
64	ASS'Y PUSH RIVET	4414H50000	2
65	SHIELD SPATTER	441G410050	1
66	BOLT HEX	7650501611	2
67	NUT HEX	7S62W50X1	2
68	STOPPER UNDER HINGE	441G448046	1
69	STOPPER TOP HINGE	3515200300	1
70	ROLLER	441V442010	4
71	ROLLER GUIDE	441G417010	1
72	TRAY	3517200400	1
73	RESISTOR MONITOR	RX10H52BJ-	1
74	SCREW TAPPING	7111300811	1
75	SCREW TAPPING	7111300811	2
76	THERMOSTAT CAVITY	441X363010	1
77	CAVITY ASS'Y	3516100300	1
78	BASE PLATE	441G411607	1
79	SCREW TAPPING	7112400811	1
80	H.V. FUSE	441Q856100	1
81	SPONGE "C"	441G478082	1
82	SPONGE	4418J78040	1
83	RESISTOR (20W 20Ω)	4419J75030	1
84	SLOW ACTING RELAY	4416W67213	1